



1. Fold the hinged halves of the bushing over the wire cable, with the tapered end pointing toward the panel.



2. Apply pliers to groove or, using hands, insert bushing into hole with one easy motion. Bushing will lock into place.