

1. Drill hole in masonry. Insert shield conical end first.
2. Use setting tool to expand lead sleeve into masonry.
3. Install work by inserting and tightening a standard machine bolt or screw.

