



Nut is threaded onto the bolt in usual way. A standard hex wrench is used to tighten. Note: Bolts should extend at least 1/4" beyond hex.



When clamping force reaches correct level, hex portion separates from conical part.



Installed conical nut presents smooth, low profile; each fastener has uniform loading and is vandal-resistant.