

maximum of 1-3/4" is recommended $A + B = UltraCon^{\otimes} length$ B + C = Depth of drilled hole. Must be at least 1/4" deeper than UltraCon® embedment